



PERIMETER FOOTINGS EXTEND BELOW FROST LINE, BUT AT LEAST TO 12" BELOW UNDISTURBED SOIL. INTERIOR FOOTINGS EXTEND AT LEAST 12" BELOW TOP OF SLAB.

DRAIN PIPES PASSING UNDER FOOTINGS ARE PROTECTED WITH ARCHES. ALL PIPE RISERS ARE SLEEVED WITH FOAM INSULATION.

SOIL IS COMPACTED BEFORE PLACING CRUSHED ROCK. CRUSHED ROCK IS COMPACTED BEFORE PLACING POLYETHYLENE VAPOR BARRIER.

REMESH IS LIFTED INTO POSITION AFTER CONCRETE IS PLACED.

