



- | | | | | | |
|---|----------------|---|-------------------|---|------------------------|
| ⊕ | DUPLEX OUTLET | ○ | LAMP, WALL | ▤ | HEAT REGISTER, FLOOR |
| ⌂ | SWITCH, ON/OFF | ⊙ | LAMP, CEILING | ▥ | HEAT REGISTER, CEILING |
| ⊗ | SWITCH, STATE | ⊖ | LAMP, FLUORESCENT | ⬠ | EXHAUST FAN |
| ⊖ | CABLE OUTLET | ◇ | CHIME BUTTON | ⬠ | SMOKE DETECTOR |
| △ | PHONE, DESK | ◇ | CHIME UNIT | ⊠ | DOOR OPENER |
| △ | PHONE, WALL | | | | |

- | | |
|---|----------------------|
| ▤ | BRACED WALL |
| ▥ | BEARING WALL |
| ▦ | BRACED BEARING WALL |
| ▧ | SOUND RESISTANT WALL |
| ▨ | ONE HOUR FIREWALL |
| ▩ | TWO HOUR FIREWALL |

- | | | | |
|---|--------------|---|----------------|
| B | BROOM CLOSET | P | PANTRY |
| C | COAT CLOSET | R | REFRIGERATOR |
| D | DISHWASHER | S | RANGE |
| F | FURNACE | T | LAUNDRY TUB |
| H | WATER HEATER | W | CLOTHES WASHER |
| L | LINEN CLOSET | Y | CLOTHES DRYER |